SEGA®

CHOPLIFTER

AN ACTION PACKED HELICOPTER GAME THAT REALLY GIVES YOU THE FEEL OF BEING AT THE CONTROLS OF A CHOPPER.

DESTROY THE ENEMIES AND RESCUE THE CAPTIVES !

Skillfully maneuver the HELICOPTER and save the prisoners while evading the enemy's fierce attack. The number of hostages you can safely deposit back at the base depends solely on your skill.

AN ULTRAEXCITING GAME !

HOW MANY HOSTAGES CAN YOU BRING BACK ALIVE ?

CHOPLIFTER

HOW TO PLAY

⊙How-to-use the lever and the 2 buttons

8-WAY LEVER To control the HELICOPTER'S movements.

SHOOT button To fire the machine gun.
To drop the bombs.

DIRECTION CHANGE

* Briefly push the button to turn the HELICOPTER from the RIGHT or LEFT to the FRONT and vice versa, and keep it pressed down to make a 180° turn.



⊙Destroy the enemy bases and fortresses with the HELICOPTER'S machine gun.
Only the bombs can destroy the tanks.

⊙Rescuing 20 HOSTAGES will allow you to proceed to the next scene.

⊙FUEL is replenished when the prisoners are returned to the base unharmed.

This game's software has been manufactured under license from Broderbund Software Inc

©Dan Gorlin 1982

SEGA creates a "High Tech Life"

SEGA®

Sega Enterprises Ltd
2-12 Haneda 1-chome Ota-ku Tokyo 144 Japan
Tel (03)743 7439 Fax (03)743 8539
Tlx J22357 SEGASTAR
Sega Enterprises Inc (U.S.A.)
2149 Paragon Drive San Jose CA 95131
U.S.A. Tel (408)435 0201 Fax (408)435 0294
Sega Europe Limited
410-420 Rayners Lane Pinner Middx HA5
5DY England Tel 01 868 2331 Tlx 893501
SEGAUK G Fax 01 429 3137

Design and specifications subject to change without notice SG-8514E

DISTRIBUTED BY: